Error Code	Description	LED Lights *(Blue Squares indicate LED's Blinking)*			
		Wash	Rinse	Spin	Door Lock
dE	Door Close Error				
tE	Washing and Drying temperature detection error				
DL	Door Lock Error				
LE1	Motor Lock Error				
PE	BP Sensor Error				
E6	Clutch Error				
FE	Overflow Error				
EE	EEPROM Error				
OE	Drain Error				
IE	Water Supply Error				
EU	Spin Cycle Entry Failure Error (Unbalance)				
PS	Incorrect Voltage (Power Supply)				
LE	Motor Lock Error				
dR	Drain Notification				
tcL	Tub Clean Notification				